



How to measure your outside window recess for roller blinds (cloth size)

- This is the measurement you need to take if you want your blind to fit on the outside of the window recess.
- Measure the exact size to cover from top to bottom and from left to right.
- We recommend overlap of 70mm on the width and 50mm on the drop, however, this is down to personal preference.
- The size that you provide will be the cloth size (material size)
- The controls and brackets are an extra 35mm wider than the cloth size.
- Most people will fit a blind with in a window recess however, this is all down to personally preference if you are looking to minimise the light coming into the room then fitting on the outside is the best option however, please note light will still be able to seep through.



Our Top Tip:

Please make sure you use a metal tape measure as cloth tape measures allow for errors.