



How to measure your outside window recess for Vertical blinds (Exact size)

- This is the measurement you need to take if you want your blind to fit on the outside of the window recess.
- Measure the exact size to cover from top to bottom and from left to right.
- We recommend overlap of 70mm on the width and 50mm on the drop, however, this is down to personal preference.
- We will make no deductions of these sizes and the width will be size the headrail and the drop from the top of the headrail to the bottom of the slats this is the complete size of your new blind including brackets so please keep in mind radiators and any other obstructions and make relevant deductions to allow your new blind to fit.



Our Top Tip:

Please make sure you use a metal tape measure as cloth tape measures allow for errors.