



HOW TO MEASURE VERTICAL BLIND SLATS

WHAT YOU NEED

- Pencil
- Note pad
- A metal tape measure



The best way to measure your existing slat (Louvre) is to lay the slat on a flat surface and measure as shown above from top to bottom ingoring hanger

USE A STEEL TAPE MEASURE